

Test and Auxiliary Functions

V → 10 20 30 40 50 60

MONITOR TEST	PRINTER TEST	X / Y	LINE TEST	MEMORY TEST	TARGET TEST
RECEIVER TEST	SWITCH TEST	SWITCH T. (on display)		MEMORY DUMP	DEADSTART / WATCHDOG TEST
REDISPLAY LAST SEQUENCE	REDISPLAY LOG (OWN HISTORY)	REDISPLAY LOG (INCLUDING CROSS SHOTS)	REPRINT LAST SEQUENCE	REPRINT LOG (OWN HISTORY)	REPRINT LOG (INCLUDING CROSS SHOTS)
SHOT SENSORS ON	SHOT SENSORS OFF	PRINT CROSS SHOTS ON	PRINT CROSS SHOTS OFF	DISPLAY CROSS SHOTS ON	DISPLAY CROSS SHOTS OFF
CROSS SHOT CHECK ON	CROSS SHOT CHECK OFF	CROSS SHOT LAMP ON	CROSS SHOT LAMP OFF		
		DEMO ON	DEMO OFF	PRINT ACTUAL OPTIONS	REINSTALL DEFAULT OPTIONS

P ↓ 1

6